

Stretch Fabric Display Frame


Assembly Guide




Step 1: Unpack the pieces and remove all the protective wrapping.



Step 2: Find the leg piece with the screw. Attach this leg piece to the base by removing the screw, positioning it to the allocated hole in the base and tightening it back up with the allen key provided.



Step 3: Once one leg is assembled, find the horizontal pole that connects the two legs. Each pole end should attach to its corresponding number. Attach this pole as shown ensuring the button is securely locked into the hole. Attach the second leg to the pole and base.



Step 4: Working your way up the frame, find the next pole by matching the numbers and attaching them accordingly. Add the horizontal bar into the allocated holes before the frame is finished, allowing you to push it into place easily.



Step 5: Your frame is now assembled. Carefully place the Stretch Fabric over the frame whilst smoothing any creases as you go.



Step 6: Ensure that the fabric is pulled down tight on the frame to create tension. Connect and close the zipper along the bottom of the fabric. You should now have a great looking Stretch Fabric Display Frame!